

Product Power Consumption for Lexmark CS431dw / C3426dw

Product Type	Color Electrophotographic Printer
Default Method to automatically enter mode	Network Standby: 15 minute delay Standby: N/A Off: 3 Day Delay auto-off or switch activated

	Network Standby					Off Mode	Standby Mode <i>w/ Reactivation Function</i>
	All Network Connections	Wired Network	Fax	USB	Wireless		
Measurement Period	24 min	28 min	N/A min	26 min	28 min	20 min	N/A
Average Power Consumption	1.19 W	1.19 W	N/A	1.41 W	1.40 W	0.08 W	N/A

Instructions for connecting to/disconnecting from a wireless network can be found in the product User Manual.

Report ID: 20191118-1101-ErP

Public Report generation date: 11/20/2019