

## Product Power Consumption for Lexmark CS531dw / C2335

Product Type	Color Electrophotographic Printer
Default Method to automatically enter mode	Network Standby: 15 minute delay Standby: 3 Day Delay Off: No auto-off; switch-activated only

	Network Standby					Off Mode	Standby Mode <i>w/ Reactivation Function</i>
	All Network Connections	Wired Network	Fax	USB	Wireless		
<b>Measurement Period (min)</b>	20	28	N/A	20	22	20	20
<b>Average Power Consumption</b>	0.72 W	0.71 W	N/A	0.62 W	0.66 W	0.12 W	0.12 W

Instructions for connecting to/disconnecting from a wireless network can be found in the product User Manual.

Report ID: 20221202-1219-ErP

Public Report generation date: 12/7/2022