

## Product Power Consumption for Lexmark CX331adwe / MC3326adwe

Product Type	Color Electrophotographic Multifunction Product
Default Method to automatically enter mode	Network Standby: 15 minute delay Standby: N/A Off: 3 Day Delay auto-off or switch activated

	Network Standby					Off Mode	Standby Mode <i>w/ Reactivation Function</i>
	All Network Connections	Wired Network	Fax	USB	Wireless		
<b>Measurement Period</b>	38 min	20 min	20 min	22 min	20 min	20 min	N/A
<b>Average Power Consumption</b>	1.07 W	1.06 W	0.97 W	0.98 W	0.97 W	0.04 W	N/A

Instructions for connecting to/disconnecting from a wireless network can be found in the product User Manual.

Report ID: 20190404-1005a-ErP

Public Report generation date: 11/21/2019